



THIS DOOR IS EQUIPPED WITH THE SCHOOL SAFE LOCKDOWN DEVICE.



NORMAL POSITION



EMERGENCY POSITION

INSTRUCTIONS

To secure the door in an emergency, flip the device so that it does not stick out beyond the door and pull the door shut until it latches.